


NAVIGATING TO THE RIGHT “CIVIL TOWN”


SWDV - 3/4/06

Step 1: navigate to the surface water data viewer.


Step 2: click on “layers” to make sure that the layers you need for your project are turned “on”.




By default, the administrative boundaries will show the following selections:



To zoom to your area of interest, click on the “zoom to” bar at the top of the page, then select ‘Civil Town’ from the drop down box:




Type the name of the Civil Town of interest into the open space:



If there is more than one, you will get both listed. The county does not currently show on this bar. This may be displayed in the future, but currently, you will have to click on the first item to see if this is the right township:

- Dunn
 - Dunn
- [Search again?](#)

When I click on the first item, the following appears. As you can see the left hand side bar does not change. If you wish to select the next item, you can do so to see if that is the appropriate selection.



When I click on the next selection I see the following:

